fuse.on

SIBA technical background information: Know-how on electrical fuses

Short circuit protection in PV systems

SIBA

400 A

CE () ()

 1100 V / 50 MA

New: Expanded Product Portfolio now up to 1500

0 028 29

Requirements for photovoltaic fuses



Short circuit protection in PV systems

Requirements for photovoltaic fuses

The current standards

Heinz-Ulrich Haas Development SIBA GmbH

Βv

1

Head of Research and meet special photovoltaic criteria defined in IEC 60269-6 (DIN EN 60269-6 - VDE 0636-6) and UL 248-19. Both standards are relatively new; the international IEC standard was published at the end of 2010, while the United States' latest UL version came out in 2015. They lay out comparable fuse requirements and even give the same name to the operating class - "gPV". [1, 2]

> Unlike standard fuses that only interrupt circuits under alternating current, these standards define fuses intended solely for direct current circuits in photovoltaic energy systems. They can interrupt the short circuits typically seen in PV systems; in other words, they interrupt fault currents that are even slightly higher than their rated current. Cycling capacity is writ large in these standards. The fuses have to withstand not only extreme thermal cycles, but complex current cycles as well. This requires the fuse and fuse element to be specially designed so they do not melt due to constant current cycling caused by passing clouds.

> However, a tiny difference between the standards has kept the standardization world on its toes: The international IEC norm states that the gPV fuse must interrupt 1.45 times the rated current within 1 h ($I_n \le 63$ A) under standard conditions, while the American UL standard sets the reference value at 1.35 times the rated current. The IEC takes this into account by definition. In a note, it states that, in <u>actual use</u>, the fuses easily interrupt 1.35 times the rated current in less than 2 h.

Standard-setters could have let this stand, but chose not to. Some members of the IEC are talking about setting 1.35 times the rated current as the reference value for the lowest breaking current for typical string fuses.





In other words, UL-listed PV fuses (and possibly faster IEC-listed fuses) may be slightly faster at a given rated current. They interrupt fault currents sooner – a feature that should be considered when designing the protection system. Figure 1 illustrates the difference.

The fuses operate more quickly because they have a higher internal resistance. This increases the amount of power dissipated by the fuse and raises the temperature of the fuse body ... which, obviously, no one wants in their PV system. However, this issue is also addressed by the standards in various protection recommendations.

2 What the standard recommends

It is fairly straightforward to select the rated current of the string fuse if you can link the fuse interrupting current to the panel fault current. When testing the panel's reverse current rating, the panel manufacturer determines the maximum rated current by running 135% of the rated current through the panel for 2 hours while ensuring that the panel does not ignite (DIN EN 61730-2). If you then install a fuse with the maximum current rating in the system, you can be sure that it will interrupt a fault current equal to 1.35 times the rated current in less than 2 hours. [3]

However, you can usually ensure better protection with a lower rated current. Annex BB of IEC 60269-6 recommends performing the calculations using the actual system fault current. Assuming an irradiance of 1200 Wm⁻² and an ambient temperature of 45 °C, you can generally arrive at a lower rated current with 1.4 x I_{sc}.

UL 248-19-listed fuses are selected using 1.56 x I_{SC} in accordance with the National Electrical Code (NEC). This allows them to handle higher irradiance levels, higher ambient temperatures up to 40 °C and a lower continuous current of the UL fuses. The recommendation made in the future IEC 60269-6 should be similar.

Fuse standard	Lowest fuse current rating	SIBA fuse type 10 x 38 mm		
IEC 60269-6	I _n ≥ 1,4 x I _{SC}	50 xxx 26		
UL 248-19 $I_n \ge 1,56 \times I_{SC}$ 50 xxx 28				
Table 1:Lowest rated current In according to the current standard for string fuses				



The sub-array fuse is responsible for protecting the conductors and PV panels from undesired reverse currents. The array fuse – the central fuse upstream of the inverter input – is intended to protect the PV conductors. The maximum rated current of the sub-array or array fuse is based on the allowed continuous current-carrying capacity of the PV conductors or cables (DIN VDE 0100-430). The IEC 62548 draft recommend a fuse current rating of 1.25 to 2.4 x I_{sc} for both applications. [4, 5]

The fuse voltage rating is based on the open circuit voltage of the panel string. It should be at least 1.2 times the open circuit voltage $U_{VO STC}$ at the lowest temperature of -25 °C.

3 What SIBA recommends

Since there were no recommendations in the standards in 2009, SIBA's <u>fuse.on</u>: <u>Just four steps to</u> <u>getting the PV fuse that suits your needs</u> described an extensive system for calculating fuse voltage and current ratings. It covered all the parameters that affect fuse rated values and has since been adopted in the field, albeit in a slightly modified form. [6]

$U_n \ge U_{OCARRAY}$	х	[1+ (Δ ዓ	х	TempKoeff of	U _{OC ARRAY})]
-----------------------	---	----------	---	--------------	--------------------------

Where $U_{OC ARRAY}$ open circuit voltage of the string

Calculation of fuse voltage rating **U**_n

 $I_n \ge I_{SCmax} / K_{TH} / A2 / K_{ZS}$

Where I _{SCmax}	max. panel fault current (for a given irradiance)
К _{тн}	Correction factor for ambient temperature
A2	Correction factor for cyclical load
K _{ZS}	Correction factor for holder grouping

Calculation of fuse current rating I_n

Frequently, higher levels of ambient temperature or irradiation power are to be considered. In these cases a more detailed calculation is necessary. Assuming a thermal radiation power of 1400 W/m² (contrarily to the standard data of 1000 W/m²) and an ambient temperature of 60°C (contrarily to the standard data of 25°C), this results in a fuse current rating as follows:

I_n ≥ I_{SCmod} * 1,7

(at a modul short circiut current of 7,9 A the fuse current should be at least 16 A)

While the former calculation is used more often concerning string protection, the higher factor has been established choosing fuses for array and sub array protection. In this case the fuse carries, too, the protection of the conductors and has to be adjusted to the I_2 of the wire.



4 Why use PV fuses?

Properly designed PV fuses protect valuable solar energy systems. They monitor system components and require no maintenance for many years. They can differentiate, too: They interrupt circuits in response to short circuits – but ignore passing clouds. Has a cable deteriorated over time, or are damaged panels producing arcs? No problem. The fuses will quickly isolate damaged components within their zones of protection.

5 SIBA fuses according to nach IEC 602169-6 und UL 248-19 (UL2579)

Size	U _n (DC)	l _n -range	Article no.	Listing
10x38	1000 V	1-20 A	5021528	UL Listed
14x51	1000 V	10-32 A	5020426	-
14x65	1100 V	10-25 A	5023528	UL Listed
14x65	1500 V	10-30 A	5024028	UL Listed
10/14x85	1100 V	10-25 A	5023828	UL Listed
10/14x85	1500 V	10-30 A	5024328	UL Listed
10x85	1500	1-16 A	5011528	UL Listed
NH00	600V	35-160 A	2018928	UL Listed
NH1	1000 V	63-200 A	2055629	UL Listed
NH2	1000 V	200-250 A	2055729	UL Listed
NH3	1000 V	315-400 A	2056829	UL Listed
SQB-101	1000 V	100-300 A	2054428	UL Listed
SQB-102	1000 V	200-400 A	2054528	UL Listed
NH1XL	1100 V	50-200 A	2002828	UL Listed
NH3L	1100 V	200-500 A	2023128	UL Listed
NH1XL	1500 V	63-200 A	2004128	UL Listed
NH3L	1500 V	200-500 A	2024328	UL Listed
SQB 3-170	1500 V	200-500 A	2024528	UL-Listed

Images see next page



Size	Fuse-link	Fuse-holder
10x38	IJ JE	a a a a
	34	Jee .
10/14x85	100 Martin	7==
		7==
14x65		
14x100	III	
NH 00 DIN 80	- Aller	and the second s
NH 1	X	Ĭ
NH 2/NH 3	X	J.
NH 1 XL		Ĩ
NH 3L		A.
	A Composition	-
SQB2 - 170	thing -	_



6 Notice

The subject of this publication is closely related to the protection of battery circuits. Concerning the latter, SIBA has prepared an information flyer. You can obtain it for free (address see rear page, or click the download link in the pdf-version of this fuse.on).

7 Bibliography

[1] DIN EN 60269-6 (VDE 0636-6): 2011-11

Low-voltage fuses - Part 6: Supplementary requirements for fuse-links for the protection of solar photovoltaic energy systems (IEC 60269-6:2010 + corrigendum Dec. 2010); German version: EN 60269-6:201

- [2] UL 248-19 Standard for Safety Fuses Part 19: Photovoltaic Fuses (Nov. 2015)
- [3] DIN EN 61730-2 (VDE 0126-30-2):2007-10;
 Photovoltaic (PV) module Safety qualification Part 2: Requirements for testing (IEC 61730-2:2004, modified); German version EN 61730-2:2007
- [4] IEC 62548

Design requirements for photovoltaic (PV) arrays (still 82/646/CDV:2011-04)

[5] DIN VDE 0100-430

Low voltage electrical installations, Part 4-43: Protection for safety – Protection against overcurrent, (IEC 60364-4-43: modified in 2008 + corrigendum in Oct. 2008, German adoption HD 60364-4-43: 2010)

[6] fuse.on Just four steps to getting the PV fuse that suits your needs, Issue 01/2009, www.siba.de

Disclaimer:

Fuses described in this document were developed to perform safety-relevant functions in a machine or complete installation. A safety-relevant system usually contains signaling devices, sensors, evaluation units and concepts for safe disconnection. Responsibility for ensuring proper overall operation lies with the manufacturer of the installation or machine. SIBA GmbH and its sales offices (hereinafter "SIBA") cannot guarantee all the features of any machine or complete installation not designed by SIBA. Once a product has been selected, it should be tested by the user in all intended applications. SIBA accepts no liability for recommendations implied or given by the above description. The description may not be construed as granting any guarantee, warranty or liability rights above and beyond SIBA's general terms of delivery.

State of the art and standards:

Technologies and technical standards are constantly changing. This document only reflects the state of the art at the time of printing. This must be taken into consideration when using the information and listed types from the product range.



fuse.on

Hauptsitz / Head Office

SIBA GmbH

Borker Straße 20-22 D-44534 Lünen Postfach 1940 D-44509 Lünen Tel.: +49-2306-7001-0 Fax: +49-2306-7001-10 info@siba.de www.siba.de

SIBA Unit Miniature Fuses

Tel.: +49-2306-7001-295 Fax: +49-2306-7001-99 elu@siba.de

Deutschland / Germany

SIBA Vertriebsbüro Freiberg

Untergasse 12 D-09599 Freiberg Tel.: +49-3731-202283 Fax: +49-3731-202462 alexander.kolbe@siba.de

SIBA Vertriebsbüro Rhein/Ruhr

Espelweg 25 D-58730 Fröndenberg Tel.: +49-2373-1753141 Fax: +49-2373-1753142 joerg.mattusch@siba.de

SIBA Vertriebsbüro Süd-West

Germersheimer Str. 101a D-67360 Lingenfeld Tel.: +49-6344-937510 Fax: +49-6344-937511 erwin.leuthner@siba.de

SIBA Vertriebsbüro Kassel

Sieberweg 20 D-34225 Baunatal Tel.: +49-5601-965300 Fax: +49-5601-965301 achim.fischer@siba.de

SIBA Vertriebsbüro Bayern

Kirchstraße 12 D-86316 Friedberg Tel.: +49-821-58955260 Fax: +49-821-58955261 guenter.heinz@siba.de



International

SIBA Sicherungen- und Schalterbau

Ges.m.b.H & Co. KG (Austria) Ortsstraße 18 · A-2331 Vösendorf bei Wien Tel.: +43-1-6994053 und 6992592 Fax: +43-1-699405316 und 699259216 info.siba@aon.at www.siba-sicherungen.at

SIBA GmbH Beijing

Rep. Office (China) Rm 1609, Block B, Lucky Tower No. 3, Dongsanhuan Beilu , Chaoyang district Beijing 100027 Tel.: +86-10-65817776 Fax: +86-10-64686648 siba_china@sibafuse.cn www.sibafuse.cn

SIBA Písek s.r.o. (Czech Rep.)

U Vodárny 1506 · 397 01 Písek Tel.: +420-38-2265746 Fax: +420-38-2265746 sibacz@iol.cz · www.siba-pojistky.cz

SIBA Sikringer Danmark A/S (Denmark)

ehemals/former Ole Andersen A/S Lunikvej 24 B · DK-2670 Greve Tel.: +45-86828175 · Fax: +45-86814565 info@sikringer.dk · www.siba-sikringer.dk

SIBA Nederland B.V. (Netherlands)

Van Gentstraat 16 NL-5612 KM Eindhoven Tel.: +31-40-2467071 Fax: +31-40-2439916 info@sibafuses.nl · www.siba-zekeringen.nl

SIBA Polska sp. z o.o. (Poland)

ul. Grzybowa 5G 05-092 Łomianki Dąbrowa Leśna Tel.: +48-22-8321477 Fax: +48-22-8339118 siba@siba-bezpieczniki.pl www.siba-bezpieczniki.pl

"SIBA GmbH" (Russia)

ul. Petrovka 27 Moskva 107031 Tel.: +7-495-9871413 Fax: +7-495-9871774 info@siba-predohraniteli.ru www.siba-predohraniteli.ru

SIBA Fuses SA PTY. LTD. (South Africa)

P.O. Box 34261 Jeppestown 2043 Tel.: +27-11334-6560 / 4 Fax: +27-11334-7140 sibafuses@universe.co.za www.siba-fuses.co.za

SIBA Far East Pte. LTD.

(South East Asia) 24 Sin Ming Lane, # 07 - 105 Midview City, Singapore 573970, Republic of Singapore Tel.: +65-66599449 Fax: +65-66594994 info@sibafuse.com.sg www.sibafuse.com.sg

SIBA (UK) LTD. (United Kingdom)

19 Duke Street Loughborough. Leics. LE11 1ED Tel.: +44-1509-269719 Fax: +44-1509-236024 siba.uk@btconnect.com www.siba-fuses.co.uk

SIBA Fuses LLC (United States of America)

29 Fairfield Place West Caldwell, NJ 07006 Tel.: +1-973575-7422 (973-575-SIBA) Fax: +1-973575-5858 info@sibafuses.com www.sibafuses.com

Weitere Vertriebspartner weltweit / Further distribution partners worldwide: www.siba.de / www.siba-fuses.com



Our Protection. Your Benefit.

Photos: Fotolia/Chalkov, GM (front page), SIBA Archiv